Notes on the Monochrome ImageWriter® I Driver

The first version of The New Print Shop® prints fine to the ImageWriter I in Draft mode, but in Final mode, the output is stretched out horizontally so that the design doesn't fit on 8.5" paper. The color ImageWriter II driver works fine in Final mode. To use this driver with the ImageWriter I the following steps should be followed:

1. In Setup, select ImageWriter II (C) even though you have a monochrome printer.

2. At the Main Menu, type Ctrl-P to toggle the color printing off. An "M" (for monochrome printing) will display in the upper left-hand corner of the Main Menu. This key command is documented on page 44 of the manual.

3. Select Final for print mode. Your project will now print correctly.

NOTE: Each time you open The New Print Shop to print in monochrome thereafter, you should type Ctrl-P to toggle from color to monochrome.